





Aluminum Frame Setup Instructions

1. Measure out the layout of your tent on the ground where you intend to set it up. Lay out your angle brackets on the ground. There should be three 3-way connectors on each end, and the 4-way connectors will connect your center rafters. There should be three 4-way brackets for every center rafter.
2. Organize your poles according to the color-coded stickers. Your leg (wall) poles will be one piece and have a black plug in the bottom (no sticker). Your rafter poles will have a red sticker on them, and your horizontal poles will have a white sticker on them. Your rafter and horizontal poles may or may not be 2 pieces depending on the size of your frame. If they are 2 pieces, fit them together and lay them out on the ground between the angle brackets.
3. Beginning at one end of the frame, begin connecting the tubing to the angle brackets. Continue until the frame is complete except for the leg poles. Your rafter system will now be ready to lay your tent over. Gently lay your tent over the frame, being sure not to catch any part of the tent on a sharp edge and thus tearing it.
4. Once your tent is on the rafter system you can now add the leg poles. Lift up one side of the tent frame and insert the leg poles into the angle brackets. Then do the same for the other side. Tighten the set screws and then pull the tent down snug over the frame.
5. Be sure and stake out the guy ropes and stakes along the bottom. Failure to do so could result in severe damage should the wind blow your tent over!




One Center Rafter

10x12



Two Center Rafters

12x14 and 14x16



Three Center Rafters

16x20